

The logo for AirsLAMIT is written in a bold, red, stylized font with a thick black outline. The letters are slightly slanted and have a dynamic, energetic feel. The 'A' is particularly large and prominent.

airslamit


Instruction Manuals

**Tow Assist With Tank Wiring and Plumbing
Diagram**

airmaxxx

Plumbing Instructions

airslamit.com
480.999.1232




Relay harness Diagram

30 Red wire to battery +

87 Red/white wire to compressor red

85 Black wire to ground

86 White wire to switch



IMPORTANT

Do not disassemble. Do not attempt repairs or modifications

This compressor will become very HOT during and immediately after use. Do not touch any part of this compressor with bare hands, during and immediately after use.

This air compressor is equipped with an Automatic Reset Thermal Protector, and can automatically restart after the thermal protector resets. Always cut off power source when thermal protector becomes activated.